

Reference

Applies to every Procura system

This page applies to all products. Product sheets list only what is specific to that system.

Tools required

- Tape measure and pencil
- Spirit level or laser level
- Cordless drill and driver
- Masonry or wood bit to suit substrate
- Allen key (supplied with locksets and extension sets)
- Flat-head screwdriver (budget locksets only)
- Rubber mallet
- Clean gloves for graphic handling

Not supplied

- Wall or ceiling fixings — substrate dependent, specify to load
- Wall plugs
- Sealant, where required by the substrate
- LED drivers and lamps, where not factory fitted

Fitting the graphic

1. Wear clean gloves. Silicone keder picks up dirt and it shows through backlit graphics.
2. Identify the top edge of the graphic before starting. Most are printed with an orientation mark.
3. Start at one corner and press the keder into the groove with your thumb, working along the rail.
4. Fit two opposite sides first, then the remaining two, easing tension evenly as you go.
5. If the keder will not seat, stop. Check it is 14x3 and that the groove is clear of swarf or sealant. Do not force it — the keder will tear.
6. To remove, start at a corner and pull the keder out at a shallow angle. Never pull perpendicular to the rail.

About the markers

- A red dot marks a figure or limit confirmed against published supplier data. •
- Anything unmarked is standard practice for this type of frame. If your substrate, format or load is unusual, confirm it with IAC before you build.

Décor

Installation – Wall or ceiling mounted, gripper track

Wall and ceiling textile system. A slim perimeter track is fixed to the substrate and the fabric is tucked into it with a spatula-type tool. The track grips the raw edge – no keder, no welt, no hem.

Before you start

Product code DEC2m

Mounting Wall or ceiling mounted, gripper track

Read the shared reference page for tools, fixings and graphic fitting. Only steps specific to this product are listed below.

Installation

1. Set out the perimeter on the wall or ceiling and check for square. On a ceiling, establish a datum first.
2. Confirm the substrate will take a fixing at reasonable centres across the whole run.
3. Fix the track to the perimeter, working from one corner. Keep the track straight – any bow will read in the finished fabric.
4. Fit acoustic fleece within the perimeter if specified, fixed to the substrate before the fabric goes on.
5. Offer the fabric up and tack it at the midpoint of each side, so the material is held square before any edge is committed.
6. Tuck the fabric into the track with the tucking tool, working opposite sides alternately and outward from the midpoints. The serrated jaw holds what you seat, so tension builds as you go.
7. Ease the corners last. Corners are where tension faults show.
8. Trim the surplus edge back to the track once all four sides are seated.
9. Any Procura textile can be used – the track grips a raw edge, so no keder or welt is required.

Warnings

- This is the only product in the range that does not use the 14x3 keder. Do not order a kedered edge for it.
- Ceiling installations are a two-person job and need working-at-height precautions.
- This system is supplied in white, grey or black – not anodized aluminium like the frame range.
- Large unbroken areas will show substrate irregularity through the fabric. Check the wall before committing.
- Fire rating follows the textile specified, not the track. Confirm the rating of the fabric before a spec submission.